

# FC-76DS Photo/Visual System Chart

- 6. CAA (SKY90) [TKA21200]
- 10. Coupling (SKY90) [TKP35001]
- 13. 50.8 Sleeve [TKP00113]
- 14. Coupling (L) [TKP00104]
- 15. Visual adapter (FS-60CB) [TKP20005]
- 16. Aux. ring (FS-60CB) [TKP20001]
- 18. 76D Reducer [TKA18580]
- 32. Camera mount DX-S (EOS) [TKA01250]  
Camera mount DX-S (Nikon) [TKA01254]
- 33. Camera mount DX-60W (EOS) [TKA20245]  
Camera mount DX-60W (Nikon) [TKA20246]
- 34. DSLR
- 36. TCA-4 [TKA00210]
- 46. Eyepiece adapter (31.7) [TKP00101]
- 47. Eyepiece (31.7)
- 48. Eyepiece (50.8)
- 49. Diagonal prism MC (31.7) [TKA00547]
- 60. Extender C2X [TKA00594]
- 67. Extender Q1.6x [TKA00595]
- 69. 50.8 adapter (SKY90) [TKP35110]
- 71. Extension Tube (50.8) [TKP27112]
- 74. Diagonal mirror [TKA00543]
- 75. Adapter (DM) [TKA00111]
- 80. 76D Flattener [TKA18582]
- 82. SD ring [TKA20583]

